

## **Diamond Glass Cabinets**

**By**

**Tobey Renee Sanders**

1. Remove the cabinets doors from the frame.
2. Remove all hardware from the doors.
3. Sand cabinets with 180 – 220 grit sandpaper and dust.
4. Prime the cabinet doors using Kilz Restoration Interior Primer. Allow to dry 4 – 6 hours. (Be sure to prop the cabinets up bricks, above the work surface.)
5. Paint your cabinet doors black, allow to dry overnight.
6. Tape off and protect part of door that will not get the Diamond Glass treatment.
7. Roll on Black Diamond Glass Glue.
8. Add desired crystals to Diamond Glass and sprinkle Diamond Glass into glue.
9. Allow to dry overnight. Brush off excess glass.
10. Topcoat the cabinet with Rust-Oleum Ultra Cover Clear Gloss. (DO NOT TOPCOAT DIAMOND GLASS)