

Ideally:

- 1.5 mm between tooth and an implant
- 1mm or more of bone on buccal and lingual side of implant
- 3mm between adjacent implants

**I suggest aiming for at least 1.5mm of bone on either side. It's a tiny distinction, but that way at least you err on the side of thicker, rather than trying to thread a needle with your implant.*

