

PRIOR TO GOING OUT TO FLY

- UPDATE FIRMWARE AND FLYSAFE DATABASE
- DRONE BATTERIES CHARGED TO 100%
- PHONE CHARGED (OR "PHONE CHARGING" IS ON)
- (OR RC IS FULLY CHARGED)
- UPDATE TO THE LATEST DJI APP
- CHECK
 - WEATHER
 - FLY MAPS
 - LOCAL LAWS FOR YOUR FLIGHT LOCATION

PACKED IN YOUR BAG

- DRONE WITH EMPTY/FORMATTED MICRO SD CARD
- SPARE BATTERIES
- CONTROLLER (WITH CORD)
- PHONE
- TRUST CERTIFICATE, PILOT'S LICENSE

OPTIONAL:

- ND FILTERS
- EXTRA MICRO SD CARD
- ALCOHOL WIPES (OR LENS WIPE)
- LAUNCH/LANDING PAD
- IF TRAVELING
 - BATTERY CHARGER
 - SPARE PROPELLORS AND TOOLS

